





INSTRUKCJA OBSŁUGI

LAMPA ŚCIENNA/ WALL LAMP

**Ostrzeżenie:**

Jeżeli zewnętrzny przewód giętki lub sznur oprawy oświetleniowej jest uszkodzony, powinien być wymieniony przez producenta, w autoryzowanym punkcie serwisowym lub u specjalisty, w celu uniknięcia ryzyka.

TEN PRODUKT ZAWIERA ŹRÓDŁO ŚWIATŁA
O KLASIE ENERGETYCZNEJ E






Gospodarstwa domowe są użytkownikami sprzętu elektrycznego i elektronicznego, a w konsekwencji potencjalnymi wytwórcami niebezpiecznych dla ludzi i środowiska odpadów, z tytułu obecności w sprzęcie niebezpiecznych substancji, mieszanin oraz części składowych. Odpowiednie postępowanie ze użytym sprzętem, w szczególności recykling, zapobiega negatywnym konsekwencjom dla środowiska naturalnego i ludzkiego zdrowia.

Symbol przekreślonego kosza na śmieci na produkcie lub w jego opakowaniu oznacza, że sprzęt elektroniczny, oraz elektryczny, baterii, oraz akumulatorów, nie wolno wyrzucać do zwykłych pojemników na odpady. Obowiązkiem użytkownika jest przekazanie użytego sprzętu do wyznaczonego punktu zbiórki w celu recyklingu odpadów powstałych ze sprzętu elektrycznego i elektronicznego.

Ten produkt jest oznaczony symbolem selektywnego sortowania, oznaczającym odpady elektryczne i elektroniczne (WEEE). Oznacza to, że z tym produktem należy postępować zgodnie z dyrektywą europejską 2012/19 / UE, aby poddać go recyklingowi lub rozebrać, aby zminimalizować jego wpływ na środowisko. Użytkownik ma możliwość przekazania swojego produktu właściwej organizacji zajmującej się recyklingiem lub sprzedawcy detalicznemu, gdy kupuje nowy sprzęt elektryczny lub elektroniczny.

USER MANUAL

LAMPA ŚCIENNA/ WALL LAMP

**Warning:**

If the outer flexible conduit or cord of the luminaire is damaged, it should be replaced by the manufacturer, at an authorized service center or by a specialist in order to avoid any risk.

THIS PRODUCT CONTAINS A LIGHT SOURCE
WITH ENERGY EFFICIENCY CLASS F.



Households are users of electrical and electronic equipment and, as a consequence, potential generators of waste hazardous to humans and the environment, due to the presence of hazardous substances, mixtures and components in the equipment. Appropriate treatment of waste equipment, in particular recycling, prevents negative consequences for the environment and human health.

The symbol with the crossed-out wheeled bin on the product or its packaging indicates that electronic and electrical equipment, batteries, and accumulators must not be disposed of in the normal waste containers. It is the user's responsibility to take the used equipment to a designated collection point for the recycling of waste electrical and electronic equipment.

This product is marked with the selective sorting symbol for waste (WEEE). This means that this product must be handled in accordance with European Directive 2012/19 / EU to recycle it or dismantle it to minimise its impact on the environment. The user has the option of handing in his product to the appropriate recycling organisation or to a retailer when purchasing new equipment electrical or electronic equipment.

The owner of the brand and the manufacturer is Action S.A.
ACTION joint-stock company, Zamienie, 10 Dawidowska St.,
05-500 Piaseczno, Poland

Made in China

safety@action.pl
activejet.com activejet.pl
hotline (PL)/ infolinia: 0 801 08 11 11

